

ALSA and au0828 resource sharing using Media Controller API Shuah Khan July 30th 2015 Media Summit, Finland shuahkh@osg.samsung.com





This is after the au8522 changes to fix the problem mentioned in the previous slide.

What are the changes?

- Managed Media Controller API
- Au8522
- V4L2 Core
- DVB Core
- Bridge driver au0828 (core and video)
- ALSA snd-usb-audio

- Managed Media Controller API
 - media_device_get_devres()
 - media_device_find_devres()
- Register Notify Interface
 - media_device_register_entity_notify()
 - media_device_unregister_entity_notify()
- New enable_source handler in struct media_device
- IRQ Safe start/stop pipeline

 Add new media controller API to allocate media device as a device resource. When a media device is created on the main struct device which is the parent device for the interface device, it will be available to all drivers associated with that interface. For example, if a usb media device driver creates the media device on the main struct device which is common for all the drivers that control the media device, including the non-media ALSA driver, media controller API can be used to share access to the resources on the media device. This new interface provides the above described feature. A second interface that finds and returns the media device is added to allow drivers to find the media device created by any of the drivers associated with the device.

 Add new interfaces to register and unregister entity notify hook to media device to allow drivers to take appropriate actions when as new entities get added to the shared media device. When a new entity is registered, all registered entity notify hooks are invoked to allow drivers or modules that registered hook to take appropriate action. For example, ALSA driver registers an entity notify hook to parse the list of registered entities to determine if decoder has been linked to ALSA entity. au0828 bridge driver registers an entity notify hook to create media graph for the device.

 Add a new field to enable source handler to find source entity for the sink entity and check if it is available, and activate the link using media entity setup link() interface. Bridge driver is expected to implement and set the handler when media device is registered or when bridge driver finds the media device during probe. This is to enable the use-case to find tuner entity connected to the decoder entity and check if it is available, and activate the using media entity setup link() if it is available. This hanlder can be invoked from media core (v4l-core, dvb-core) as well as other drivers such as ALSA that control the media device.

- ALSA driver calls Media Controller start/stop pipeline interfaces from IRQ handler. Start/stop pipeline lock graph_mutex which is unsafe from a IRQ handler. Convert graph_mutex into a spinlock and call it graph_lock. IRQ safe start/stop pipeline interfaces will be added based on this change.
- Several drivers that use graph_mutex are changed in this patch series.

Au8522 Driver Changes

 Add new pad for ALSA Audio Out to au8522_media_pads. Move the au8522_media_pads enum to au8522.h from au8522_priv.h. This will allow au0828-core to use these defines instead of hard-coding the pad values when it creates media graph linking decode pads to other entities.

V4L2-core Changes

 Add a new interface to be used by v4l-core to invoke enable_source handler in the media_device to find tuner entity connected to the decoder and check is it is available. enable_source handler will activate the link if tuner is available.

V4L2-core Changes ...

 Change s_input, s_fmt, s_tuner, s_frequency, querystd, s_hw_freq_seek, and vb2_streamon interfaces that alter the tuner configuration to check for tuner availability by calling v4l_enable_media_tuner(). If tuner isn't free, return -EBUSY.

Dvb-core Changes

- Checking for tuner availability from frontend thread start disrupts video stream. Change to check for tuner and start pipeline from frontend open instead and stop pipeline from frontend release.
- DVB-core should use enable_source Fix in the next patch series.

Bridge driver (au0828) changes

- Change au0828 to use Managed Media Controller API to coordinate creating/deleting media device on parent usb device it shares with the snd-usb-audio driver. With this change, au0828 uses media_device_get_devres() to allocate a new media device devres or return an existing one, if it finds one.
- Registers register_notify handler to create media graph for the device. Creates necessary links between video, vbi, and ALSA entities.
- Implements enable_source hanlder for other drivers to use to check for tuner connected to the decoder and activate the link if tuner is free.

Au0828 video driver changes

- au0828-video will initialize decoder field struct video_device for v4l-core to use it when it invokes enable_source hanlder.
- au0828 is changed to use enable_source hanlder to check for tuner availability from vidioc_g_tuner(), au0828_v4l2_close(), and queue_setup() prior to changing tuner settings. If tuner isn't free, return busy condition.

 Change ALSA driver to use Managed Media Managed Controller API to share tuner with DVB and V4L2 drivers that control AU0828 media device. Media device is created based on a newly added field value in the struct snd_usb_audio_quirk. Using this approach, the media controller API usage can be added for a specific device. In this patch, Media Controller API is enabled for AU0828 hw. snd usb create quirk() will check this new field, if set will create a media device using media device get devres() interface.

 Change ALSA driver to use Managed Media Managed Controller API to share tuner with DVB and V4L2 drivers that control AU0828 media device. Media device is created based on a newly added field value in the struct snd_usb_audio_quirk. Using this approach, the media controller API usage can be added for a specific device. In this patch, Media Controller API is enabled for AU0828 hw. snd usb create quirk() will check this new field, if set will create a media device using media device get devres() interface.

- media_device_get_devres() will allocate a new media device devres or return an existing one, if it finds one.
- During probe, media usb driver could have created the Managed media device. It will then register the media device if it isn't already registered. Media device unregister is done from usb_audio_disconnect().

 Media device is created based on a newly added field value in the struct snd usb audio quirk. Using this approach, the media controller API usage can be added for a specific device. In this patch, Media Controller API is enabled for AU0828 hw. snd usb create quirk() will check this new field, if set will create a media device using media device get devres() interface. device if it isn't already registered. Media device unregister is done from usb audio disconnect().

- New structure media_ctl is added to group the new fields to support media entity and links This new structure is added to struct snd_usb_substream.
- A new entity_notify hook and a new ALSA capture media entity are registered from snd_usb_pcm_open() after setting up hardware information for the PCM device.

 When a new entity is registered, Media Controller API interface media device register entity() invokes all registered entity notify hooks for the media device. ALSA entity notify hook parses all the entity list to find a link from decoder it ALSA entity. This indicates that the bridge driver created a link from decoder to ALSA capture entity.

 ALSA will attempt to enable the tuner to link the tuner to the decoder calling enable source handler if one is provided by the bridge driver prior to starting Media pipeline from snd usb substream capture trigger(). If enable source returns with tuner busy condition, then SNDRV PCM TRIGGER START will fail with -EBUSY. Media pipeline is stopped in response to SNDRV PCM TRIGGER STOP.

References

- Please find the patch series at:
 - https://git.kernel.org/cgit/linux/kernel/git/shuah/linux.git/log/?h=media_controller